

KALIBRACIJSKI CERTIFIKAT

Calibration certificate

NAROČNIK
Costumer
5Labs d.o.o.
Legen 112, 2380 Slovenj Gradec

LASTNIK
Owner
5Labs d.o.o.
Legen 112, 2380 Slovenj Gradec

MERILO
Object
Merilne kladice • Gauge blocks

IDENTIFIKACIJA
Identification
1200907
PROIZVAJALEC
Manufacturer
Schut

TIP
Type
Kasa 1
MERILNI OBSEG
Meas. range
(2,5 - 25) mm



**SLOVENSKA
AKREDITACIJA**
SIST EN ISO/IEC 17025
LK-034

Slovenska akreditacija je podpisnica večstrankarskih sporazumov o priznavanju akreditacijskih organov z Evropsko akreditacijo (EA - MLA) in Mednarodnim združenjem za akreditacijo laboratorijev (ILAC - MRA). Slovenian Accreditation is signatory to the multilateral agreements on recognition of accreditation bodies with the European Accreditation (EA - MLA) and International Laboratory Accreditation Cooperation (ILAC - MRA).

KRAJ KALIBRACIJE
Place of calibration
Slovenj Gradec

DATUM KALIBRACIJE
Date of calibration
4. 04. 2024

DATUM PREJEMA
Date of receipt
4. 04. 2024

OPOMBE
Notes

ODOBRIL
Approved by
Petra Oprešnik

Dovoljeno je razmnoževanje le celotnega certifikata. Verodostojnost podpisa je mogoče preveriti v elektronski obliki certifikata. Only the reproduction of the complete certificate is allowed. Signature validity can be verified in electronic version of certificate

1. KALIBRACIJSKI POSTOPEK • Calibration procedure

Kalibracija merilnih kladic je bila izveden v skladu z interno proceduro KL-5Labs-15, ki temelji na standardu ISO 3650. Obsega določitev odstopanja srednje dolžine in/ali variacije.

Calibration of gauge blocks was carried out in accordance with the internal procedure KL-5Labs-15, which is based on standard ISO 3650 and covers the determination of deviations of medium length and / or variation.

2. KALIBRACIJSKI POGOJI • Calibration conditions

Temperatura • Temperature $(20 \pm 1) ^\circ\text{C}$

3. SLEDLJIVOST • Traceability

Oznake certifikatov pri kalibraciji uporabljenih etalonov

Calibration marks of standards used at calibration

28258	132021		
-------	--------	--	--

Ta kalibracijski certifikat dokumentira sledljivost do (inter) nacionalnih etalonov v skladu z mednarodnim sistemom merskih enot (SI).

This calibration certificate documents the traceability to (inter) national standards, which realize the units of measurement according to the International System of Units (SI).

Kalibracijski certifikati zgoraj navedene opreme uporabljene pri kalibraciji so javno objavljeni na naši spletni strani pod https://www.5labs.si/index.php/open_documents

The calibration certificates of the above mentioned equipment used at calibration are publicly available on our website at https://www.5labs.si/index.php/open_documents

4. MERILNA NEGOTOVOST • Measuring uncertainty

$$U = 0,05 \mu\text{m} + 6,7 \cdot 10\text{E}-6 \cdot L$$

Merilna negotovost je podana kot standardna negotovost meritve pomnožena s faktorkem $k = 2$, ki pri normalni porazdelitvi ustreza verjetnosti 95%. Standardna merilna negotovost je določena v skladu s publikacijo EA-4/02.

The specification indicates the expanded measuring uncertainty resulting from multiplication of standard measuring uncertainty by the factor $k = 2$. It was determined in conformity with EA-4/02. The values of the measurement parameter lie within the specified range with a probability of 95%.

5. RAZLAGA REZULTATOV • Result explanation


Podani merilni rezultati in pripadajoča merilna negotovost se nanašajo samo na to kalibrano merilo. Izmerjene vrednosti veljajo v času meritev in ne zagotavljajo dolgotrajne stabilnosti.

The measurement results and uncertainties quoted refer only to this calibrated gauge. The measurement results are valid at the time of measurement and do not guarantee long-term stability.

Za korekcijo merilnih rezultatov na $20 ^\circ\text{C}$ je bila uporabljena linearna temperaturna razteznost $\alpha = 11,5 \cdot 10\text{E}-6 / \text{K}$. • For the correction of measurement results on $20 ^\circ\text{C}$ was used linear thermal expansion coefficient $\alpha = 11,5 \cdot 10\text{E}-6 / \text{K}$.

Za korekcijo merilnih rezultatov na $20 ^\circ\text{C}$ je bila uporabljena linearna temperaturna razteznost $\alpha = 11,5 \cdot 10\text{E}-6 / \text{K}$. • For the correction of measurement results on $20 ^\circ\text{C}$ was used linear thermal expansion coefficient $\alpha = 11,5 \cdot 10\text{E}-6 / \text{K}$.

6. MERILNI REZULTATI • Measurement results



Identifikacija • Identification	Nominalna vrednost L • Nominal value [mm]	Odstopanje sredinske dolžine • Deviation of median length [μm]	Razpon dolžine • Length range [μm]	Zgornje odstopanje od sredinske dolžine • Upper deviation from center length [μm]	Spodnje odstopanje od sredinske dolžine • Lower deviation from center length [μm]	Opomba (Razred po ISO 3650) • Note (Class by ISO 3650)
	L_n	L_c	v	F_o	F_u	
120069	2,500	0,08	0,08	0,00	0,07	0
110946	5,100	-0,05	0,10	0,03	0,05	0
110332	7,700	0,01	0,07	0,00	0,08	0
110480	10,300	0,06	0,06	0,00	0,09	0
110366	12,900	0,01	0,09	0,00	0,10	1
112274	15,000	0,06	0,06	0,00	0,08	0
110357	17,600	0,03	0,07	0,00	0,10	0
110285	20,200	-0,01	0,09	0,00	0,08	0
110267	22,800	0,12	0,12	0,00	0,09	0
114291	25,000	0,00	0,12	0,00	0,12	1